

Reach information diagram





Delivery scope Standard Line

Adjustment options with machine fault manage (EGD-RC)	ment
Agitator safety switch off, with startup protec	tion
Bolted I-frame	
Bolted pipe holders	
Boom rest RFID-monitored	
Box for sponge balls	
CAN-Bus system	
Cardan shaft maintenance free	
Combined lubrication: auto lubrication of hop A-joint and slewing ring. Cycles adjustable.	per,
Concrete hopper with agitator	
Connection for filling water tank	
Contamination indicator hydraulic oil filter	
Delivery cylinder chrome-plated	
Delivery note-box, plastic	
Diagnose interface	
EOC – Ergonic Output Control	

EPS - E	rgonic Pump System
Ergonic	2.0
Ergonon	nic water hose reel at riser pipe
Fail-safe	S transfer tube
Flushing	water pump 160 I/min 25 bar
Fully end	closed side for simple cleaning
Hand rai	l at water tank, right hand side
Hinged e	elbow with cleaning port
Hose for	cleaning 10 m incl. bracket and spray nozzle
Hydrauli	c fluid cooler integrated in the support leg
Hydrauli	c hose for replacement in hose pack
LED ligh	ting control box
LED ligh	ting control sections
LED ligh	ting hopper
Mainten	ance free pins rear support leg
Mainten	ance-optimized suppoert cylinder
Operatin	g manuals 2× (1× paper, 1× CD-ROM),

Painting: 3-coloured Putzmeister standard
Platform non-skid
Radio remote control ergonic 2.0 with display, also using with cable
Rubber collar on concrete hopper
S-transfer tube switchover fast/slow
Spectacle wear plate DURO 22
Splash guard foldable
Support plates (4×)
Wash-out port lid with secured sliding pin
Water supply at hopper
Water tank 800 I
Wear reduced delivery line elbow with extension

See quotation for exact serial delivery scope.
Comprehensive range of options available on request.

both sides

Putzmeister Concrete Pumps GmbH | P.O. Box 2152 | 72629 Aichtal | Tel. +49 7127 599-0 | Fax +49 7127 599-520 | pmw@pmw.de Right to make amendments reserved | © by Putzmeister | All rights reserved | Printed in Germany | 1805