




Reach information diagram, Support



* depends on chassis
Dimensions can differ depending on configuration.

 Range in which you must not work with the end hose.